Important Safety Notice Recall

Delta Stem Raiser, Delta Stem Raiser Pro, QBP Dimension Steerer

Extender Delta Cycle



manufactured by Corp

The instructions for these items do not have the correct torque specification for the installation/side bolts. The bolts should be tightened to 20nm. If the raiser is not properly tightened it can present a fall hazard.

Please follow the steps below to fix this problem.

- 1) If you own TD3318B, TD3318S, SM1977 (height is 5.3") please contact stemrecall@deltacycle.com/800-474-6615 with your name and address for new bolts. Items TD3418B, TD3418S, SM1979 (height is 6.5" & will have height markers) do NOT require new bolts.
- 2) A trained bicycle technician should tighten (or install if needed per step 1) bolts to 20nm. The retailer where you purchased this product can assist you with this process.

visible height markers/no new bolts needed new bolts supplied



must tighten to 20nm

Questions??? Contact stemrecall@deltacycle.com or



800-474-6615

This recall is being conducted in cooperation with the U.S. Consumer Product Safety Commission deltacycle.com/stemrecall